


## INSTALLATION MANUAL: 210K221 (VESPA CIAO)

HPI – Kuilenstraat 97, 3960 Bree, Belgium  
TEL: (0032) 089-46 74 39 | FAX: (0032) 089-47 33 28 | GSM: (0032) 0495-53 90 21  
Email: hpi@hpi.be | Website: www.hpi.be

To install the universal ignition on a Vespa Ciao, first you'll need to mill down the parts indicated with a white arrow to 2mm **lower** than the center ring (red arrow), but **DO NOT** mill down the center ring!!



Then, install the universal ignition as you would normally do (see next page).

